



## Set-up instructions for SH3212A:

1. Snap 2x #2 rods into the vertical holes of 4x 'D' connectors. This will form the width of the base.
2. Connect 4x #1 rods in the other vertical hole of the 'D' connectors. Then, attach them in the middle with 2x 'A' connectors. This will form the length of the base.
3. Join 6x #3 rods into the vertical holes of all the connectors on the base.
4. Add four more 'A' connectors on the four corners, then snap 4x #1 rods in the vertical holes. Secure them in the middle via 2x 'C' connectors.
5. Snap in 4x #4 angled rods into the vertical holes of the 'A' connectors on all corners. Attach them with 2x 'D' connectors.
6. Add two more #4 angled rods into the vertical holes of the two 'C' connectors in the middle. Join them with the 'E' connector.
7. Lastly, add 2x #1 rods into the vertical holes of the top 'D' connectors on the ends and the 'E' connector in the middle.
8. The frame is now ready. Drape the tent cover over it. Fasten it with green ties.
9. Use the zippers to access the interior.