



Set-up instructions for SH3214A:

1. Using the vertical holes of 4x 'D' connectors, form a square base with 4x #1 rods.
2. Then, snap 4x #3 rods into the vertical holes of the connectors.
3. Add 4x 'A' connectors on the top end of these #3 rods and attach 4x #2 rods in the vertical holes.
4. Join the #2 rods in the middle (on both sides) with additional 'A' connectors.
5. Snap 6x #4 angled rods in the vertical holes of all six 'A' connectors.
6. Attach them using 2x 'J' connectors on both ends.
7. Add two more #2 rods in the vertical ends of the 'J connectors', then secure them using the 'H' connector in the middle.
8. Drape the tent cover on top of the frame.
9. Fasten the cover with the green ties.
10. Use the zipper to access the interior.