



Set-up instructions for SH7005-ZD:

Tool Required: Phillips Screwdriver

Step 1: Slide the longer ends of 2x trapezoid sides into 1x short aluminum extrusion. Secure the connection using 1x black triangular shaped groove at the bottom center.

Step 2: Connect 2x rectangular sides by sliding them into the shorter end of the trapezoid sides. Secure them at the bottom using black triangular grooves and black L-shaped grooves on the top.

Step 3: Repeat Step 1 for the last side, connecting the shorter ends of trapezoid into the rectangular sides. Secure via L-shaped grooves on the top and triangular grooves at the bottom.

Step 4: On the top of the short aluminum extrusion, insert 2x triangular grooves on the inside.

Step 5: Slide the longest aluminum extrusion into these triangular grooves.

Step 6: Slide 2x rectangular gates into the aluminum extrusion.

Step 7: Fasten 4x Wings into the holes on trapezoid-sides using the supplied hexes and shorter hex bolts.

Step 8: Insert the 4x metal teeth into the rectangular gates on both sides using nylon insert locks and bolts.